

Yard
Management
System

Switcher Manual

Table of Contents

Topic:	Slide:
• Login	3
• Job Detail	6
• Trailer Inspection	13
• Trailer Audit	15

Login

The screenshot shows the login interface of the Yard Management System. At the top, there is a navigation bar with buttons for "Logout", "Job List", "Change Team", "Inspection", and "Audit", along with the "WhereNet" logo. The main area contains two input fields: "Operator:" with the text "sraymond" and "Password:" with masked characters. Below the "Operator:" field, a red arrow points to the text "Enter ACE ID then press <Enter>". Below the "Password:" field, a red arrow points to the text "Enter password then press <Enter>". At the bottom right, a red arrow points to a "Login" button, with the text "Press the Login button to sign in" next to it.

Logout Job List Change Team Inspection Audit WhereNet

Operator: sraymond Password: *****

Enter ACE ID
then press
<Enter>

Enter password
then press
<Enter>

Press the Login
button to sign in → Login

Logout Job Detail Change Team Inspection Audit

Choose Starting Zone

Spotter Parking

Select starting zone

Press OK

OK

Connection: **Connected** Operator: admin Team: <ALL>

Job Detail

The screenshot shows a web application interface for the Yard Management System. At the top, there is a navigation bar with buttons for 'Logout', 'Job Detail' (highlighted in yellow), 'Change Team', 'Inspection', and 'Audit'. The 'WhereNet' logo is visible in the top right corner. Below the navigation bar is a header for 'Job Detail'. The main content area is a large, light-colored rectangle with the text 'Waiting For Job' centered in a large, red, pixelated font. At the bottom of the interface, there is a status bar with several indicators: 'Connection: Connected' (green), 'Operator: sraymond', 'Team: <ALL>', and 'Job Not Assigned' (red).

'Waiting For Job' displays when there are no moves currently available for the switcher team, or while the system is calculating which job to assign to the switcher

Server
connection
status

Current
user

Switcher
zone

Text
messag
e


Connection:

Connected

Operator: **sraymond**

Team: **<ALL>**

Job Cnt: **10 of 71**

 **Message**

Trailer Number, Owner, and From and To locations of trailer

Users can update the final location of a trailer if it is placed in a different location than originally intended. First select the new location group of the trailer, then the actual location it was placed. If original spot was occupied by another trailer, enter it in the final drop down

Jobs can be mapped by clicking Map It button

Trailer inspection can be performed by clicking Inspect button

Logout Job Detail Change Team Inspection Audit

Job Detail Door Type: Rollup

383503
(COMMON FLEET)

FROM: C10 TO: DK156

New Location Group: Foreign OB 1

New Location: DK156


DK156 Occupied By: Find

Refresh Map It Inspect Unselect


Connection: Connected Operator: admin Team: <ALL> Job Assigned

Click the Pick button once the switcher has hooked up to the trailer

Logout	Job Detail	Change Team	Inspection	Audit
Job Detail		Door Type: Rollup		
FROM: C10		383503 (COMMON FLEET)	TO: DK156	
New Location Group :	Foreign OB 1	Pick		
New Location:	DK156			
DK156 Occupied By:		Find		
Refresh	Map It	Inspect	Unselect	
Connection: Connected	Operator: admin	Team: <ALL>	Job Assigned	

Logout Job Detail Change Team Inspection Audit 

Mapping a job is useful if the driver is new, the trailer is parked in a non-designated area, or the trailer is parked in a designated area that has a large capacity



Move destination

Current Trailer Location

Map options

Job Detail

Connection: **Connected** Operator: **straymond** Team: **<ALL>** Job Assigned

Click the Complete button once the switcher has fully completed the move and is detached from trailer

Logout	Job Detail	Change Team	Inspection	Audit
Job Detail		Door Type: Rollup		
FROM:	383503 (COMMON FLEET)	TO:	DK156	
New Location Group :	Foreign OB 1	Complete		
New Location:	DK156			
DK156 Occupied By:		Find		
Refresh	Map It	Inspect	Unselect	
Connection: Connected	Operator: admin	Team: <ALL>	Job Assigned	

Trailer Inspection

Select the area of the trailer that is being inspected

Check box to set inspection failure

Press Edit/View button to enter additional information

Logout Job List Change Team **Inspection** Audit WhereNet

Carrier: SWIFT TRANSPO Trailer: SWFT536992
Area: Exterior

Sev.	Inspection Point	Notes
<input type="checkbox"/>	1 Cross Members	
<input type="checkbox"/>	1 End-Clip Fasteners	
<input checked="" type="checkbox"/>	1 Base/Top Rails	
<input type="checkbox"/>	1 Side Walls	
<input type="checkbox"/>	2 Rear Impact Guard	
<input type="checkbox"/>	2 Landing Gear	

Edit/View...

Connection: Connected Operator: sraymond

Inspection Details - SWFT536992

Exterior: Base/Top Rails Failed

Description:
If severely damaged, consult supervisor with questions. NOT bent, cut, cracked or corroded.

Failure Notes

Enter information here

Cancel OK

Trailer Audit

Trailers locations can be audited by zone or by individual trailer

Logout Job Detail Change Team Inspection **Audit**

Audit

By Zone

By Trailer

Connection: **Connected** Operator: admin Team: <ALL> **Job Not Assigned**

Select the location group and spot within that group that the switcher will start auditing

Information about each location will be available

Press Audit button to change information about a location

Logout
Job Detail
Change Team
Inspection
Audit

Audit By Location

Location Group:
Start From:

Location	Trailer	Cap	Type	Process Status	Load Status	Audit
A01	NJF26006	0	28T	Inbound	MTE	Audit
A02	50512	1		Unloaded-Hand	Empty	Audit
A03	2028010	1	28T	Unloaded-Hold	Empty	Audit
A04	383665	1	45T	Inbound	MTE	Audit

Top
Page Up
Page Down
Bottom
Cancel

Connection: Connected
Operator: admin
Team: <ALL>
Job Not Assigned

Trailer number currently assigned to location will display here

If trailer assigned to the location is incorrect, click minus button

Enter correct trailer number in drop down field and click the plus button

Click Submit button to finalize

Logout Job Detail Change Team Inspection **Audit**

Audit By Location

Location: Row A - A01 Capacity: 0

Find Clear

383503 + -

Submit Cancel

Connection: **Connected** Operator: admin Team: <ALL> **Job Not Assigned**

Type in trailer number that will be audited, click Find button

Logout Job Detail Change Team Inspection Audit

Audit By Trailer

Trailer: 383503 Find

Owner	Trailer	Type	Process Status	Load Status	
215	383503	45T	Realign - Pull	IB Mail - Ready	Audit

Top Page Up Page Down Bottom Cancel

Connection: Connected Operator: admin Team: <ALL> Job Assigned

Trailer information will show here

Click Audit to change trailer information

Current trailer information will be listed here

Enter any necessary changes into drop down menus

Click Submit button to finalize

Logout Job Detail Change Team Inspection **Audit**

Audit Trailer

Trailer:	383503*	Owner:	215
Location Group:	Foreign OB 1	Process Status:	Realign - Pull
Location:	DK156	Load Status:	IB Mail - Ready

New Loc Group: Foreign OB 1 New Process Status: Realign - Pull

New Loc: New Load Status: IB Mail - Ready

Submit Cancel

Connection: **Connected** Operator: admin Team: <ALL> **Job Assigned**